

# 1

### LIGHT CLEANING

Franke recommends initially cleaning the sink by using a magic sponge (if available) and water or mild detergent and a soft cloth to fully degrease the surface.

The sink should be scrubbed using a circular motion - to ensure the contours of the sink surface are all exposed to the cleaning fluid. Rinse thoroughly with clean water and dry the sink.



MAGIC ERASER

OR



FOR EVERYDAY CLEANING



### HEAVY CLEANING

For heavier stains where step 1 is not successful and the staining is NOT suspected to be due to limescale Franke recommend cleaning the sink using proprietary cleaning products such as Jif and a soft cloth or sponge to fully remove the stain.

The sink should be cleaned using a circular motion to ensure the contours of the sink surface are all exposed to the cleaning fluid. Rinse thoroughly with clean water and dry the sink.

# 2



FOR STUBBORN MARKS



### HOW TO REMOVE LIMESCALE

In the event of limescale staining Franke recommends step 1 as above followed by cleaning the surface of the sink with a proprietary limescale remover (for example - 'Easy Off BAM Power Cleaner Soap Scum & Shine')

Franke recommend leaving limescale remover on the surface of sink for 1 minute (or the time specified on the specific cleaning product). Wipe the sink with a soft cloth or sponge to fully clean the surface. Rinse thoroughly with clean water and dry the sink.

# 3

